

U-POL PREMIUM AEROSOL SELECTOR CHART



DRIVING SURFACE PERFECTION™

Product	Part Number	Color	DIRECT TO METAL			Plastic	Fiberglass	Painted Surfaces	Polyester Body Fillers & GRP	Gloss Level %	SHAKE	SURFACE PREPARATION		COATS	AIR DRYING	COVERAGE	DRY BUILD	REGULATORY
			Bare Steel	Aluminum	Galvanized Steel										SQ FT PER UNIT	MIL	MIR	
CLEAR#1	UP0796	Clear						√		85+	2 mins	-	1-2 coats @ 10"	60 mins	16.4	1.4	CC: 0.85	
WELD#2	UP0768	Copper	√		√					-	2 mins	P80 - 240 wet or dry P180	1-2 coats @ 10"	10-20 mins	20.8	0.4	WTP: 1.00	
WELD#2	UP0789	Zinc	√		√					-	2 mins	P80 - 240 wet or dry P180	1-2 coats @ 10"	10-20 mins	19.9	0.4	WTP: 1.00	
SPOT#3	UP0870	Gray	√	√	√	√	√	√	√	-	2 mins	P180 - 320 wet or dry P180	1-2 coats @ 10"	15-20 mins	14.6	0.6	ABP: 0.95	
GRIP#4	UP0799	Clear	√	√	√	√	√	√	√	-	2 mins	Degrease/Light Abrasion	1-2 coats @ 10"	10-20 mins	22.0	0.1	PAP: 2.50	
HIGH#5	UP0763V	White	√	√			√	√	√	-	2 mins	P180 - 240 wet or dry P180	1-2 coats @ 10"	60 mins	10.9	1.4	ABP: 0.95	
HIGH#5	UP0765V	Dark Gray	√	√			√	√	√	-	2 mins	P180 - 240 wet or dry P180	1-2 coats @ 10"	60 mins	11.3	1.4	ABP: 0.95	
HIGH#5	UP0783V	Beige	√	√			√	√	√	-	2 mins	P180 - 240 wet or dry P180	1-2 coats @ 10"	60 mins	8.6	1.4	ABP: 0.95	
HIGH#5	UP0791V	Gray	√	√			√	√	√	-	2 mins	P180 - 240 wet or dry P180	1-2 coats @ 10"	60 mins	10.8	1.4	ABP: 0.95	
HIGH#5	UP0871	Black	√	√			√	√	√	-	2 mins	P180 - 240 wet or dry P180	1-2 coats @ 10"	60 mins	9.9	1.4	ABP: 0.95	
WIPE#6	UP0872	Clear	√	√	√	√	√	√	√	-	-	-	-	-	-	-	-	
GUIDE#7	UP0873	Black						√	√	-	2 mins	As Required	1 coat @ 10"	-	26.3	-	FCP: 0.80	
ACID#8	UP0741V	Gray	√	√	√		√	√	√	-	2 mins	P180 - 240 wet or dry P180	1-2 coats @ 10"	10-20 mins	21.5	0.6	ABP: 0.95	
ACID#8	UP0837	Black	√	√	√		√	√	√	-	2 mins	P180 - 240 wet or dry P180	1-2 coats @ 10"	10-20 mins	27.0	0.6	ABP: 0.95	
BLEND#9	UP0874	Clear						√		-	-	-	1 coat @ 10"	-	-	-	-	
GUARD#10	UP0875	Black	√	√	√		√	√	√	-	2 mins	-	1-2 coats @ 10"	3-4 hours	19.2	2.0	ABP: 0.95	
GUARD#10	UP0884	Gray	√	√	√		√	√	√	-	2 mins	-	1-2 coats @ 10"	3-4 hours	19.3	2.0	ABP: 0.95	
TRIM#11	UP0876	Gloss Black				√		√		70+	2 mins	P400 - 600 wet or dry P400	1-2 coats @ 10"	20-30 mins	14.5	1.0	ABT: 1.70	
TRIM#11	UP0877	Matte Black				√		√		-	2 mins	P400 - 600 wet or dry P400	1-2 coats @ 10"	20-30 mins	13.2	1.0	ABT: 1.70	
TRIM#11	UP0878	Satin Black				√		√		15-25	2 mins	P400 - 600 wet or dry P400	1-2 coats @ 10"	20-30 mins	13.6	1.0	ABT: 1.70	
TRIM#11	UP0879	Gloss White				√		√		70+	2 mins	P400 - 600 wet or dry P400	1-2 coats @ 10"	20-30 mins	10.1	1.0	ABT: 1.70	
TRIM#11	UP0880	Steel Wheels				√		√		-	2 mins	P400 - 600 wet or dry P400	1-2 coats @ 10"	20-30 mins	11.3	0.6	ABT: 1.70	
TRIM#11	UP0881	Silver Wheels				√		√		-	2 mins	P400 - 600 wet or dry P400	1-2 coats @ 10"	20-30 mins	17.7	0.6	ABT: 1.70	
E-COAT#12	UP0890	Black	√	√			√	√	√	30-40	2 mins	P180 - 320 wet or dry P180	1-2 coats @ 10"	20-30 mins	17.3	1.0	ABP: 0.95	
E-COAT#12	UP0891	Gray	√	√			√	√	√	30-40	2 mins	P180 - 320 wet or dry P180	1-2 coats @ 10"	20-30 mins	16.2	1.0	ABP: 0.95	
E-COAT#12	UP0892	Light Green	√	√			√	√	√	30-40	2 mins	P180 - 320 wet or dry P180	1-2 coats @ 10"	20-30 mins	16.2	1.0	ABP: 0.95	
E-COAT#12	UP0893	Beige	√	√			√	√	√	30-40	2 mins	P180 - 320 wet or dry P180	1-2 coats @ 10"	20-30 mins	16.2	1.0	ABP: 0.95	
E-COAT#12	UP0894	Olive Green	√	√			√	√	√	30-40	2 mins	P180 - 320 wet or dry P180	1-2 coats @ 10"	20-30 mins	16.2	1.0	ABP: 0.95	
E-COAT#12	UP0895	White	√	√			√	√	√	30-40	2 mins	P180 - 320 wet or dry P180	1-2 coats @ 10"	20-30 mins	16.2	1.0	ABP: 0.95	

Many substrates need to be properly prepared before application for proper adhesion. √ does not indicate direct to substrate application. Please refer to the corresponding TDS before beginning any repair.