

U-POL Application Guide

Recommended Procedure for Obtaining Consistent Results

UP2043 Dry Powder Guide Coat Aerosol

UP2043 Dry Powder Guide Coat is a ready to use aerosol that highlights and identifies surface imperfections on:

- Body fillers
- Putty / Glaze
- Primer

Process Tools Required:		
UP2043 Guide Coat		

1. CLEAN REPAIR AREA



Clean area to ensure surface is free of dust by wiping with lint free cloth or blowing off with clean compressed air.

2. SHAKE UP2043 GUIDE COAT



Shake can thoroughly for 1 minute

3. APPLY GUIDE COAT



Apply 1 light even coat over filler, putty or primed area to be sanded.

4. DRY TIME



Allow Guide Coat to dry 1 minute before sanding.

5. SANDING



UP2043 Guide Coat can be wet or dry sanded. Being a dry powder, UP2043 will not cause clogging or loading of the sandpaper.



U-POL Technical Support:
1-800-340-7824

U-POL US, 630 Municipal Drive, Suite 300, Nazareth, PA 18064
T: 800-340-7824 F: 610-743-8654 sales-us@u-pol.com www.u-pol.com